

Aberrations

Aberrations:
review

Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses

- From the Merriam-Webster online dictionary: **ab·er·ra·tion** (*n*):
 - ① The fact or an instance of being aberrant (straying from the right or normal way) especially from a moral standard or normal state.
 - ② Failure of a mirror, refracting surface, or lens to produce exact point-to-point correspondence between an object and its image.
 - ③ Unsoundness or disorder of the mind.

plus other definitions. . .

- We described the aberration a of a wave in terms of the distance along a ray direction of the actual wave crest relative to the ideal wave crest.
- You saw from Prof. Walter how the Hubble Space Telescope was fabricated with spherical aberration, which was corrected for with the COSTAR upgrade.

Atmospheric turbulence

Aberrations:
review

Adaptive optics


Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses

- Why do the stars twinkle? Because of dynamic rearrangements of the optical path length through the atmosphere. Dynamic aberrations. . .
- Refractive index depends on density. Air has $n = 1 + 8 \times 10^{-5}$, with $n - 1$ varying linearly with pressure and temperature.
- Timescale for rearrangement within aperture of typical telescopes is ~ 5 msec, or 200 Hz.




Atmospheric disturbance versus altitude at Cerro Paranal, Chile. Dashed line: altitude-integrated disturbance.

<http://www.ctio.noao.edu/~atokovin/tutorial/part2/dm.html>

Wavefront correction

This is what we'd like to do, using a “guide star” (small, isolated star near what we want to image):



From Wikipedia

See [this movie](http://cfao.ucolick.org/ao/) which is from <http://cfao.ucolick.org/ao/>.

Sensing wavefront distortions

Aberrations:
review


Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses



Shack-Hartmann wavefront sensing scheme.

<http://www.ucolick.org/~max/289C/>

Rubber mirrors

Aberrations:
review

Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses

Deformable Mirror


Rear View

349 Actuators
on 7 mm spacing



Front View

146 mm diameter
clear aperture



Keck telescope adaptive mirror.

Mini rubber mirrors

Aberrations:
review


Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses



<http://www.ucolick.org/~max/289C/>

Adaptive optical systems

Aberrations:
review


Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses



From <http://cfao.ucolick.org/ao/>

Adaptive optics successes

Aberrations:
review


Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses



From <http://cfao.ucolick.org/ao/>

Chromatic dispersion and lenses

Aberrations:
review

Adaptive optics

Chromatic
dispersion

Abbe diagram


Achromats

Complex lenses

Recall that we found for the refractive index in the visible range the expression

$$n \simeq 1 + A \left(1 + \frac{B}{\lambda^2} \right)$$

This was based on a damped, driven harmonic oscillator model with a resonance at a particular frequency. Different glasses have different resonant frequencies in the UV and thus different A and B in the visible.



<http://en.wikipedia.org/wiki/Image:Dispersion-cu>

Dispersion in glasses

Aberrations:
review

Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses


Glasses are often characterized in terms of response at three particular Fraunhofer spectral lines:

$$\lambda_F = 486.1 \text{ nm} \quad \lambda_D = 589.2 \text{ nm} \quad \lambda_C = 656.3 \text{ nm}$$

It's common to specify things in terms of the center wavelength λ_D and then do a linear approximation of the dispersion curve:

$$\frac{\partial n}{\partial \lambda} = \frac{n_F - n_C}{\lambda_F - \lambda_C} \quad \text{or alternatively} \quad V \equiv \frac{n_D - 1}{n_F - n_C} \quad (1)$$

where V is called the Abbe number or constringence.



Dispersion II

Aberrations:
review

Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses


Again, we have:

$$\frac{\partial n}{\partial \lambda} = \frac{n_F - n_C}{\lambda_F - \lambda_C} \quad \text{or alternatively} \quad V \equiv \frac{n_D - 1}{n_F - n_C}$$

Some example glasses, including their catalog code $n_D - 1/10V$:

	n_C	n_D	n_F	V	$n_D - 1/10V$
Borosilicate crown	1.51461	1.51707	1.52262	64.55	517/645
Flint	1.61564	1.62045	1.63198	37.97	620/380
Fused silica	1.45637	1.45846	1.46313	67.83	458/678

Abbe diagram



Modifying Abbe's number

Aberrations:
review


Adaptive optics

Chromatic
dispersion

Abbe diagram


Achromats

Complex lenses



Achromat I

- Chromatic: of color.
- **A**chromat: **no** color-dependence in imaging.
- Let's see if we can put two lenses together to have their dispersions cancel.
- Let the lenses be thin so that we add their refractive powers:



$$\frac{1}{f_D} = \frac{1}{f_{1D}} + \frac{1}{f_{2D}} \quad (2)$$

$$\begin{aligned} &= (n_{1D} - 1) \left(\frac{1}{r_{11}} - \frac{1}{r_{12}} \right) + (n_{2D} - 1) \left(\frac{1}{r_{21}} - \frac{1}{r_{22}} \right) \\ &= (n_{1D} - 1)K_1 + (n_{2D} - 1)K_2 \end{aligned} \quad (3)$$

We want to have $1/f_D$ be constant over a given wavelength range.

Achromat II

Again, we want to have $1/f_D$ be constant over a given wavelength range,
or

$$\frac{\partial}{\partial \lambda} \left(\frac{1}{f} \right) = 0 = K_1 \frac{\partial n_1}{\partial \lambda} + K_2 \frac{\partial n_2}{\partial \lambda} = K_1 \frac{n_{1F} - n_{1C}}{\lambda_F - \lambda_C} + K_2 \frac{n_{2F} - n_{2C}}{\lambda_F - \lambda_C} \quad (4)$$

Look at one of these terms in more detail:

$$\begin{aligned} K_1 \left(\frac{n_{1F} - n_{1C}}{\lambda_F - \lambda_C} \right) \left(\frac{n_{1D} - 1}{n_{1D} - 1} \right) &= K_1 \left(\frac{n_{1F} - n_{1C}}{n_{1D} - 1} \right) \left(\frac{n_{1D} - 1}{\lambda_F - \lambda_C} \right) \\ &= (n_{1D} - 1) K_1 \frac{1}{V_1 (\lambda_F - \lambda_C)} \\ &= \frac{1}{f_{1D}} \frac{1}{V_1 (\lambda_F - \lambda_C)} \end{aligned} \quad (5)$$

which means we can write our achromat condition as

$$\frac{1}{f_{1D}} \frac{1}{V_1} + \frac{1}{f_{2D}} \frac{1}{V_2} = 0 \quad (6)$$

Achromat III

Aberrations:
review

Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses

We now have two equations and two unknowns:

$$\frac{1}{f_{1D}} \frac{1}{V_1} + \frac{1}{f_{2D}} \frac{1}{V_2} = 0 \quad \Rightarrow \quad \frac{1}{f_{1D}} = -\frac{1}{f_{2D}} \frac{V_1}{V_2}$$

$$\frac{1}{f_D} = \frac{1}{f_{1D}} + \frac{1}{f_{2D}} \quad \Rightarrow \quad \frac{1}{f_{1D}} = \frac{1}{f_D} - \frac{1}{f_{2D}}$$

so we can combine them:

$$\begin{aligned} -\frac{1}{f_{2D}} \frac{V_1}{V_2} &= \frac{1}{f_D} - \frac{1}{f_{2D}} \\ \frac{1}{f_D} &= \frac{1}{f_{2D}} \left(1 - \frac{V_1}{V_2} \right) \end{aligned} \quad (7)$$

$$\text{or} \quad f_{2D} = f_D \left(1 - \frac{V_1}{V_2} \right) \quad \text{or} \quad \frac{1}{f_{2D}} = \frac{1}{f_D} \frac{V_2}{V_2 - V_1} \quad (8)$$

Achromat IV

Aberrations:
review

Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats


Complex lenses

We can then find $1/f_{1D}$ from

$$\begin{aligned}\frac{1}{f_{1D}} &= \frac{1}{f_D} - \frac{1}{f_{2D}} = \frac{1}{f_D} - \frac{1}{f_D} \frac{V_2}{V_2 - V_1} \\ &= \frac{1}{f_D} \left(\frac{V_2 - V_1 - V_2}{V_2 - V_1} \right) = \frac{1}{f_D} \frac{V_1}{V_2 - V_1}\end{aligned}\quad (9)$$

OK, so we have expressions for f_{1D} and f_{2D} . Can we determine the radii of curvature?

Let's choose $r_{11} = +|r_1|$, $r_{12} = -|r_1|$, and $r_{21} = -|r_1|$.



Achromat V

Aberrations:
review

Adaptive optics


Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses

Again, we want $r_{11} = +|r_1|$, $r_{12} = -|r_1|$, and $r_{21} = -|r_1|$. This lets us find a condition for the focal length of the first lens:



$$\begin{aligned}\frac{1}{f_{1D}} &= \frac{1}{f_{1D}} \frac{V_1 - V_2}{V_1} = (n_{1D} - 1) \left(\frac{1}{r_{11}} - \frac{1}{r_{12}} \right) \frac{V_1 - V_2}{V_1} \\ &= (n_{1D} - 1) \frac{2}{|r_1|} \frac{V_1 - V_2}{V_1}\end{aligned}\quad (10)$$

so we want $V_1 > V_2$.

Achromat V

Aberrations:
review

Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses

What about the second lens?

$$\frac{1}{f_{2D}} = (n_{2D} - 1) \left(\frac{1}{r_{21}} - \frac{1}{r_{22}} \right) = (n_{2D} - 1) \left(-\frac{1}{|r_1|} - \frac{1}{r_{22}} \right) = \frac{1}{f_D} \frac{V_2}{V_2 - V_1} \quad (11)$$

But $1/f_D = (n_{1D} - 1)(2/|r_1|)(V_1 - V_2)/V_1$ so

$$\begin{aligned} -(n_{2D} - 1) \left(\frac{1}{|r_1|} + \frac{1}{r_{22}} \right) &= (n_{1D} - 1) \frac{2}{|r_1|} \frac{V_1 - V_2}{V_1} \frac{V_2}{V_2 - V_1} \\ &= -(n_{1D} - 1) \frac{2}{|r_1|} \frac{V_2}{V_1} \\ \frac{1}{|r_1|} + \frac{1}{r_{22}} &= \frac{(n_{1D} - 1)}{(n_{2D} - 1)} \frac{2}{|r_1|} \frac{V_2}{V_1} \\ \frac{1}{r_{22}} &= \frac{1}{|r_1|} \left[2 \frac{(n_{1D} - 1)}{(n_{2D} - 1)} \frac{V_2}{V_1} - 1 \right] \quad (12) \end{aligned}$$

So we've done it! We've found that one can design a lens which has no chromatic aberrations at least for a narrow wavelength range about a single wavelength λ_D .

Complex lens design

Aberrations:
review


Adaptive optics

Chromatic
dispersion

Abbe diagram

Achromats

Complex lenses



This shows an Olympus zoom lens set for two different focal lengths. High quality zoom lenses have a very complicated design! Notice the achromat doublets in there?